

UNIVERSITY VIDEO NETWORK (U.V.N.) OPERATIONS

MZ 112

Equipment Preparation

1. Use EPSON remote to turn on the data projector; Select **Video** as input source
2. Turn on VCR; tune to **assigned channel** by pressing the channel up/down button
3. Turn on the amplifier; select **DVD** as the sound source; adjust volume if necessary
If UVN scroll is seen on screen, proceed to use the phone to activate the UVN system.




Note: If all settings are correct but there is no UVN signal, check to see if VCR is set to **CABLE** by pressing the Action or Menu button on the VCR remote.

UNIVERSITY VIDEO NETWORK (U.V.N.) OPERATIONS

Using the Phone to Access the UVN System

1. Dial assigned phone extension and wait for the beep.
2. Upon hearing the beep, the phone pad becomes your remote control.
3. See diagrams below for number keys and their corresponding functions.
4. Leave phone off the hook during the show so you may use remote functions at any time.
5. When finished, stop the video and hang up the phone.
6. If classroom phone is faulty, use cell phone to activate the system by dialing 1-818-677-EXTENSION.
7. For further UVN assistance and/or to report phone problems, call extension 2688.

VHS Remote Control



DVD Remote Control

