

California State University Northridge

UNIVERSITY VIDEO NETWORK (U.V.N.) OPERATIONS

MZ 130

Equipment Preparation

1. Use the Epson remote to turn on the data projector; select **VIDEO** as input source
2. Turn on the VCR
3. Tune to **assigned channel** by pressing Channel up/down button
4. Turn on the tuner.
5. Select **Video** as the input source; adjust volume if necessary




Note: If all settings are correct but there is no UVN signal, check to see if VCR is set to **CABLE** by pressing the Menu or Action button.

UNIVERSITY VIDEO NETWORK (U.V.N) OPERATIONS

Using the Phone to Access the UVN System

1. Dial assigned phone extension and wait for the beep.
2. Upon hearing the beep, the phone becomes your remote control.
3. See diagrams below for number keys and their corresponding functions.
4. Leave phone off the hook during the show so you may use remote functions at any time.
5. When finished, stop the video and hang up the phone.
6. If classroom phone is faulty, use cell phone to activate the system by dialing (818) 677-EXTENSION.
7. For further UVN assistance and/or to report phone problems, call extension 2688.

VHS Remote Control



DVD Remote Control

