

STANDARD OPERATING PROCEDURES Industrial Steamer

DO NOT use this equipment unless you have received authorization from the Shop Coordinator



Closed-toe footwear must be worn.



Secure loose clothing, hair, and jewelry.

Potential Hazards and Injuries

▲ Electric Shock/Electrocution

⚠ Burns/Scalding

Pre-Operational Safety Checks

- Allow the appliance to cool completely before adding water.
- ✓ Unplug from electrical outlet when filling with water.
- Ensure cord and device are not damaged or worn. Report damaged or malfunctioning equipment immediately, then tag and remove it from operation.
- Ensure rods are tightened securely before operating.
- Ensure power cord is plugged directly into a wall outlet. Do not use an extension cord.
- Check appliance operation before each use by holding it away from body and operating.

Safe Practices During Operation

- Steam only in an up and down vertical motion. Tilting the steamer handle may result in hot water discharge.
- When steaming in a low position near the floor, extend hose up and out frequently to keep clear of condensation.
- Ensure cord does not touch hot surfaces.
- Ensure there is always water in the tank while operating.
- ✓ Keep face, hands, and body away from steam. Never direct steam at people or animals (do not steam clothing while on body)

Ending Operations and Cleaning Up

- ✓ Turn off and unplug appliance after each use. Release excess steam.
- ✓ Hang steam head in an upright position in the hose hanger section when not in use.
- ✓ Take care when emptying the reservoir, as there may be hot water inside.
- Periodically, empty the reservoir to avoid sediment buildup and maintain proper water level.

DON'T

- On not use the steamer for anything except its intended use.
- On not use an extension cord.
- Never direct steam head towards people or animals. Never steam clothing while on body and never place hands in front of steam head.
- Never operate steamer without water. Never allow to run dry.
- Do not overfill reservoir.
- Do not use additives such as salt, vinegar, bleach, or perfumes. The only exception is cleaning products provided by the manufacturer.
- Never attempt repairs yourself. Report damaged equipment, then tag and remove it from operation.
- Never use steam head in a horizontal or backwards-tilted position, this may result in hot water discharge.
- Never immerse the appliance in water or other liquids
- Never tug cord to disconnect from outlet; instead grasp plug and pull to disconnect.
- Never move the appliance by pulling the power cord.
- Do not leave appliance plugged in while filling with water, emptying, or when not in use.